## **POND DESIGN DATA**

Job Class	Soils		Hydro. Gr		
Land Use	·	Trtmt	Condition	1	
Rainfall Dist.	Type II or III DA	۹ ac. ۱	N/S Slope	%	
Slope Factor	Slop	e Interpolation	factor (SIF)		
CN	Rainfall (ps)	in	yr. Vr =	_ in.	
Vs = [(	_ ac. +	_ac.) / 2] x	ft. =	_AF	
Vs (in.) = [(V:	s) AF x	12]/(DA)	AC =	in.	
Use Vs= in. & Vr= in. FR Fig. 1, READ TAB A OR B					
(II) Qi(ps) = [Qpeak(ps)] cfs x (SIF) = cfs					
(III) la/P =; Qpeak(ps) = cfs/ac/in					
Qi(ps) = [Qpeak(ps) x (Vr) x (DA) x (SIF)					
	) =				
Qo(ps)=(TAE	3 A or B)	x	cfs or ac. =	cfs	
			rrel; in. rise		
			O. (es) =		
(II) Qes = [C	Qpeak(es)]	cfs x (SIF)	=	cfs	
(III) la/P = _	; Qpeak	(es) =	_ cfs/ac/in		
Qes =	= [Qpeak(es)]	x [R.O.(es)	)] x (DA)	_x (SIF)	
Qes =	= cfs	<b>;</b>			
			=	cfs	
Erosion Resistant Soil: (yes or no) Cover					
Cond. Stand	Height	in. to _	in. Slope	%	
Vel	fps Retardan	ce: Stab	Capacity	·	
Control-Section Length = ft. q/ft.=					
			.) =		
Use: BW =	ft. Hp	o =	_ft. S/W SS =	:1	
			Adequate		
Embankmen	t SS =	_:1 TW =	ft.		
Freeboard =	ft. El	Riser	_ El Emer S/W		
El Top of Dai	m Set	tlement	_ % Pond Use _		
Capacity = 0.	.4 x a	c. x	_ft. =	AF	
Barrel	ft. of	in		Pipe	
Riser	ft. of	in		Pipe	
Valve	in Colla	ars ft.x	ft.x ff		
Trash Rack of	or Sleeve	in. x		ft.	
Flotation = (E	3) (W) _	x (H)	/ 87.6 =	CF	
Concrete (PA	AD) CF	+ (ASC)	CF / 27 =	CY	
Quantity of Fill CY Veg ac.					
Design By	esign By Checked By				